Journal of Computer Science 3 (8): 624-632, 2007 ISSN 1549-3636 © 2007 Science Publications

Teaching Computer Organization and Architecture Using Simulation and FPGA Applications

Dr. Kasim M. Al-Aubidy

Computer Engineering Department, Philadelphia University, P O Box 1, Jordan, 19392

Abstract: This paper presents the design concepts and realization of incorporating micro-operation simulation and FPGA implementation into a teaching tool for computer organization and architecture. This teaching tool helps computer engineering and computer science students to be familiarized practically with computer organization and architecture through the development of their own instruction set, computer programming and interfacing experiments. A two-pass assembler has been designed and implemented to write assembly programs in this teaching tool. In addition to the micro-operation simulation, the complete configuration can be run on Xilinx Spartan-3 FPGA board. Such implementation offers good code density, easy customization, easily developed software, small area, and high performance at low cost.

Key Words: Teaching tool, Computer organization and architecture, Processor design, Microprogramming, Assembler design, FPGA implementation.

INTRODUCTION

Computer organization and architecture is a common course that is offered at universities throughout the world ^[1]. Traditionally, teaching such a course to computer engineering and computer science students can be insufficient if the teaching focus is solely on textbook materials ^[2,3]. Students often have to rely on their imaginations to understand the underlying hardware-related concepts. In most universities, students learn computer design concepts by software implementing individual pieces of a computer. This approach has several limitations, while students can simulate their design using software, they don't have the chance to realize or run their design in hardware ^[4]. Also, it is not feasible to build a laboratory that can provide various computer architectures for teaching computer organization and architecture. Hence, keeping computer education up-to-date requires keeping in touch with the rapid evolution of the computer technology and industry. Searching for an efficient way of teaching computer organization and architecture is an ongoing task ^[2]. An active tool will be considered in this paper for teaching computer organization and architecture by taking advantage of simulation and Field Programmable Gate Array (FPGA) technology [5,6]

FPGA technology offers the potential of designing high performance systems at low cost. FPGAs have been used for many computational tasks ^[6], and this paper presents the micro-operation simulation of a basic computer and its implementation on an FPGA. Field programmable gate arrays consist of programmable logic blocks, which can each implement a small amount of digital logic, and programmable routing which allows the logic block inputs and outputs to be connected to form larger circuits ^[7,8,9].

FPGAs have become a popular technology for creating digital systems since they can lead to a shorter time-to-market for designs than application-specific circuits (ASICs) and allow design modifications to be made after system creation ^[10]. The primary method used for validating a design with most FPGA design flows is simulation.

This paper presents the micro-operation simulation and FPGA realization of a single cycle computer, which can be used for educational purposes. This simulation is a set of micro-operations that represent the register transfer statements of all operations that can be implemented. Also, it covers the design of an assembler for the designed computer, which can be used for educational purposes. The student can obtain a better understanding of the internal operation of a computer by simulating each element, and this will help students to study the design and performance issues.



Fig. 1: Teaching Tool Layout

COMPUTER ORGANIZATION TEACHING TOOL

The design of the computer's instruction set is an important architectural issue. The processor structure and the functionality of the instructions define the computer's behavior. The objective of this work is to design a simple computer that will introduce the singlecycle computer features to the students. The internal organization of a digital system is defined by sequence of micro-operations that perform on data stored in its registers. The computer is capable of executing various micro-operations and can be instructed to perform a sequence of operations.

I 1	Io	Op-Code	Address/Data	
15	14	13 10	9	0
		Fig. 2: In	struction Format	

Each component in the proposed computer was designed using Verilog HDL. Some components (e.g. Main Memory, Registers, ...etc) have several modules in order to enable the user to choose his own architecture. To realize this choice a special GUI software was developed with multiple values selection for each component. These components include:

- Main Memory Size, which specifies the size of the address field in the instruction format; and then the size of address related internal registers.
- Total number of instructions.
- Type of instructions; memory-reference (MRI), register reference (RRI) and input/output reference (IOI) instructions, which results in determining number of cycles automatically.
- Computer Instructions; specify the required instructions and their type to determine the size of the operation code in the instruction format and size of the op-code register automatically.
- Addressing Modes; which leads to determine the number of required bits in the instruction format.
- Status Flags; specify the required flags such as carry flag, zero flag and interrupt flag.

Once a student selects the design parameters, their values are written into a file used by the main module in the Verilog HDL code in order to build the required architecture. Then this architecture is downloaded into the FPGA using Project Navigator Package via USB port, see Fig.1.

DESIGN EXAMPLE

Instruction codes together with data are stored in memory. The computer reads each instruction from memory and places it in a control register. The control unit then interprets the binary code of the instruction and proceeds to execute it by issuing a sequence of micro-operations. An instruction code is a group of bits that instruct the computer to perform a specific operation. It is made up of 16 bits, and divided into three parts, as shown in Fig.2. Two bits (I_1,I_0) to specify the addressing mode, four bits binary code to specify the operation, and ten bits address field. Table 1 illustrates the addressing mode of the proposed computer, which is used to:

- Reduce the number of bits in the address field of the instruction, and
- Give user flexibility in dealing with counters, pointers ... etc

A computer needs registers for manipulating data and a register for holding a memory address. Nine registers are required for the proposed computer, as shown in Table 2.

Table 1: Addressing Modes.

I1	Io	Addressing mode
0	0	Immediate addressing (\$ address)
0	1	Direct addressing
1	1	Indirect addressing (# address)

Table 2: Basic Computer Registers.

Register	Bits No.	Function
Memory Buffer Reg. (MBR)	16	Holds memory word
Memory Address Reg	. 10	Holds address for memory
(MAR)		
Address Reg. (AR)	10	Holds operand/instruction add.
Accumulator (AC)	8	Processor register
Counter Reg. (CR)	8	Holds count for loops
Program Counter (PC)	10	Holds address of instruction
Operation Reg. (OPR)	4	Holds code of operation
Input Reg. (INP)	8	Holds input character
Output Reg. (OUTR)	8	Holds output character

Some registers (such as AC, MAR, and MBR) may receive data from several multiplexed sources. A basic computer has eight registers, a memory unit, and a control unit. Paths must be provided to transfer information from one register to another and between memory to registers. A more efficient scheme for transferring information in a system with many registers is to use a common bus. A multiplexer can be used to design the common bus. The connection of the registers to the common bus system is shown in Fig. 3.

Computer Instructions: A basic computer has three basic instruction code formats. A memory-reference instruction uses ten bits to specify either an address or an operand and two bits to specify the addressing mode (I_0,I_1) . For immediate addressing it is 00, 01 for direct addressing, and 11 for indirect address. The register-reference instructions are recognized by the operation code 1111 and a 00 in the left most bits of the instruction. A register-reference instruction specifies an

operation on the AC register. An operand from memory is not needed; therefore, the other 10 bits are used to specify the operation to be executed.



16-bit common bus

Fig. 3: Basic Computer Registers Connected to a Common Bus.



Fig. 4: Flowchart of Instruction Cycle

		1
Туре	Symbol	Description
	NOP	No operation
	ADD	Add memory word to AC
su	SUB	Subtract memory word from AC
, îtio	AND	AND memory word to AC
лı	OR	OR memory word to AC
nst	XOR	XOR memory word to AC
еI	LDA	Load memory word to AC
înc	STA	Store content to AC in memory
ere	BUN	Branch unconditionally
Ref	BSA	Branch and save return address
<u>v</u>	DSZ	Decrement and skip if zero
Memo	LDC	Load CR
	RET	Return
	BZ	Branch if zero
	BC	Branch if carry
	CLA	Clear AC
s ce	CLS	Clear all status flags
on	CMA	Complement AC
efe ıcti	SRA	Shift right AC
Reg. Re Instru	SLA	Shift left AC
	INC	Increment AC
	HALT	Terminate program
	INP	Input character to AC
Reference tructions	OUT	Output character from AC
	SKI	Skip on input flag
	SKO	Skip on output flag
	ION	Interrupt on
0 Ins	IOF	Interrupt off
I.	SFI	Set input flag
	SFO	Set output flag

Table 3: Basic Computer Instructions.

Similarly, an input-output instruction does not need a reference to memory and is recognized by the operation code 1111 and 11 in the left most bits of the instruction. The remaining 10 bits are used to specify the type of the input-output operation. This technique allows having up to 35 different operations, as given in Table 3.

Timing and Control: The timing for all registers in the basic computer is controlled by a master clock generator. The control signals are generated by the control unit and provide control inputs for the multiplexer in the common bus, control inputs in processor registers, and micro-operations for the accumulator. The control unit, Fig. 3, consists of three decoders, a sequence counter, and a number of control logic gates. The control unit gets the operation code from the OPR through a 4x16 decoder. Bits 14 & 15 of the instruction code are transferred to two flip-flops designated by the symbols $I_0 \& I_1$. Bits 0 through 9 are applied to the control logic gated directly from the MBR through the common bus. The outputs of the counter are decoded into 4 timing signals T_0 through T_3 . The sequence counter (SC) can be incremented or cleared. Most of the time, the counter is incremented to provide the sequence of timing signals out of the 2x4 decoder. Once, the counter is cleared, causing the next

active timing signal to T_0 . The decoder is used to determine the cycle to be performed.

INSTRUCTION CYCLES

A program residing in the memory unit of the computer consists of a sequence of instructions. Each instruction cycle is subdivided into a sequence of subcycles. The value of three flip-flops is entered into a decoder to determine the cycle to be served, as illustrated in Table 4. As illustrated in Fig. 4, each instruction cycle is divided into the following five subcycles:

Fetch and Decode Cycle: Initially, the program counter is loaded with the address of the first instruction in the program. The sequence counter is cleared to 0, providing a decoded timing signal T_0 . After each clock pulse, sequence counter is incremented by one, so that the timing signals go through a sequence T_0 , T_1 , T_2 and T_3 . The micro-operations for the fetch and decode cycle can be specified by the following statements:

$C_0 T_0 : PC \rightarrow MAR$	
$C_0 T_1 : M(MAR) \rightarrow MBR, PC + 1 -$	\rightarrow PC
$C_0 T_2 : MBR < I_0, I_1 > \rightarrow (I_0, I_1),$	
$MBR < OP_Code > \rightarrow OPR$,
$MBR \ < Address \ > \rightarrow \ AR$	
$\overline{I_0}C_0T_3: 1 \to R, 1 \to F, 0 \to G$	(Execute Cycle)
$\overline{I_1}I_0C_0T_3: O \rightarrow R, \ 1 \rightarrow F, \ 0 \rightarrow G$	(Direct Cycle)
$I_1I_0C_0T_3: 1 \rightarrow R, 0 \rightarrow F, 0 \rightarrow G$	(Indirect Cycle)

	Table	4:.	Cycles	Combin	ation
--	-------	-----	--------	--------	-------

Flip-	flops		
G	F	R	Cycle
0	0	0	Fetch & Decode
0	0	1	Indirect
0	1	0	Direct
0	1	1	Execution
1	0	0	Interrupt

Indirect Cycle: At this cycle, the effective address of the operand is to be read from the memory. The register AR holds the address of memory word which contains the effective address of the operand:

 Direct Cycle: The effective address of the operand may be read during two time pulses. Therefore, to disable the delay of waiting for T_3 , the sequence counter may be cleared at time T_2 . Thus, the next time pulse will be T_0 of the execution cycle and not T_3 of the indirect cycle:

$$\begin{array}{rcl} C_2 T_0 & :AR & \rightarrow & MAR \\ C_2 T_1 & :M(MAR) & \rightarrow & MBR, \\ C_2 T_2 & :1 \rightarrow & R, & 1 \rightarrow & F, & 0 \rightarrow & G, \\ & & 0 \rightarrow & CC & (Execution & Cycle) \end{array}$$

Execute Cycle: At this cycle, the fetched instruction (register-reference, memory reference, or input-output-reference) is executed. The type of the instruction is decided according to:

- If $q_{15} = 0$, then RRI.
- If $q_{15}\overline{I_1I_0} = 1$, then RRI.
- If $q_{15}I_1I_0 = 1$, then IOI.



Fig .5: Basic Computer Block Diagram

Symbol	Miro-operations						
ADD	$q_0C_3T_0: AC + MBR < Data > \rightarrow AC$						
OR	$q_3C_3T_0: AC \cup MBR < Data > \rightarrow AC$						
ST A	$q_6C_3T_0$: AR \rightarrow MAR, AC \rightarrow MBR < Data >						
31A	$q_6C_3T_1$: MBR < Data > \rightarrow M(MAR)						
	$q_8C_3T_0: PC \rightarrow MBR < Address >, AR \rightarrow MAR$						
DCA	$q_8C_3T_1: MBR < Address \rightarrow M(MAR),$						
DSA	$AR+1 \rightarrow AR$						
	$q_8C_3T_2:AR \to PC$						
LDC	$q_{10}C_3T_0$: MBR < Data > \rightarrow CR						
	$q_{11}C_3T_0: 0 \to MAR$						
RET	$q_{11}C_3T_1: M < MAR > \rightarrow MBR$						
	$q_{11}C_3T_2$: MBR < address> \rightarrow PC						
CLA	$rB_0T_0: 0 \to AC$						
SRA	$rB_{3}T_{0}$: SHR(AC) \rightarrow AC, $0 \rightarrow$ AC(7)						
INP	$pB_0T_0: INPR \rightarrow AC, 0 \rightarrow FGI$						
SKO	pB_3T_0 : IF(FGO = 1) then PC + 1 \rightarrow PC						
Where:							
$\mathbf{r} = \mathbf{q}_{15} \mathbf{I}_1 \mathbf{I}_0 \mathbf{C}_3$, Common to all RRIs.							
$B_n = MI$	$B_n = MBR(n)$, [MBR (0-9) that specifies the operation]						
$p = q_{15}$	$I_1 \overline{I_0} C_3$ (Common to all IOIs).						

 Table 5: Control functions and micro-operations for selected instructions

Interrupt Cycle: The interrupt cycle is initiated after the execute cycle if the interrupt flip-flop (INF) is equal to 1. The flip-flop is set to 1 manually using a switch, and it may be set during the execution of the program by the instruction ION. The flip-flop is reset to 0 whenever the interrupt is served or by the instruction IOF.

This basic computer serves the interrupt by saving the next sequential instruction in memory address 0, and then it starts execution from address 1 in the memory. The micro-operations required for this instruction are:

$$C_4T_0: PC \rightarrow MBR < Data >, 0 \rightarrow INF$$

$$C_4T_1: 0 \rightarrow PC, 0 \rightarrow MAR$$

$$C_4T_2: MBR < Data >\rightarrow M(MAR), PC + 1 \rightarrow PC$$

 $C_4 T_3: 0 \to R, 0 \to F, 0 \to G$ (Fetch Cycle)

Register Transfer Statements: A register transfer language is useful not only for describing the internal organization of the computer, but also for specifying the logic circuits needed for its design. The implemented computer has 35 instructions, as in Table 3. Each instruction is represented by a single statement or a set of statements. Table 5 illustrates the control functions and micro-operations for selected instructions. The obtained statements give all the information necessary for the design of the logic circuits of the computer.

The schematic diagram of the basic computer is given in Fig. 5. It is compound of one 16-bit register, three 10-bit registers, four 8-bit registers, one 4-bit register, eight D-Flip-flops, one 1024x16-bit RAM, one ALU, one 8-bit inverter, two 2-to-1 Multiplexer, one 4-to-1 Multiplexer, one 4-to-16 decoder, one 3-to-8 decoder, one 2-to-4 decoder, and one 2-bit sequence counter.

ASSEMBLER DESIGN

A two pass assembler has been designed and implemented to write assembly programs and use the output of the assembler to run these programs on the basic computer. Figure 6 shows the files used as input and those generated as output by the assembler. These are;

- Source File (input): It is a text file containing the source program to be assembled. It has a ".asm" extension. It consists of two segments, the code segment followed by the data segment. The data segment starts with "data:".
- Binary Code File (output): It contains the assembled statements represented in binary form. This file is stored in the block memory, and it has a ".dat" extension.
- Hex Code File (output): It contains the assembled statements in hexadecimal form. This file is stored in the external memory, and it has a ".mem" extension.
- Listing file (output): It consists of the source file statements, the assembled code, and the Branch Vector Table *BVT*. This file has a ".*lst*" extension.

The basic computer assembly language character set consists of the following subset of the standard ASCII character set:

- Lower-case letters (a to z).
- Digits 0 through 9.
- Blanks (ASCII 32).

Assembler Instructions: Any assembly program for the basic computer consists of text lines, and each line contains only one instruction and an optional comment. Table 6 shows all instructions and their appropriate operands and addressing modes.

A symbolic destination must be placed at the beginning of the line of code for branching to a line of assembly code. A line that begins with comment symbol (//) is considered a comment line. It is printed into the list (.lst) file but will not be encoded into the

hex (.mem) and the binary (.dat) files. Comments may be added to lines that contain program code.



Fig. 6: Assembler Input and Output Files.

Table	6: Possible Types for Ea	ach Assembly Instructions
Instr.	Type of operand	Function
nop	-	No operation
add	Immediate data/Add.	Add operand to AC
sub	Immediate data/Add.	Subtract operand from AC
and	Immediate data/Add.	AND operand to AC
or	Immediate data/Add.	OR operand to AC
xor	Immediate data/Add.	XOR operand to AC
lda	Immediate data/Add.	Load operand to AC
sta	Address	Store AC content in memory
bun	Label	Branch unconditionally
bsa	Label	Branch and save return add.
dsz	-	Decrement and skip if zero
ldc	Immediate data/Add.	Load CR
ret	-	Return
bz	Label	Branch if zero
bc	Label	Branch if carry
cla	-	Clear AC
cls	-	Clear all status flags
cma	-	Complement AC
sra	Immediate data	Shift right AC
sla	Immediate data	Shift left AC
inc	-	Increment AC
halt	-	Terminate program
inp	-	Input character to AC
out	-	Output character from AC
ski	-	Skip on input flag
sko	-	Skip on output flag
ion	-	Interrupt on
iof	-	Interrupt off
sfi	-	Set input flag
sfo	-	Set output flag

Example: To write an assembly program for the implemented basic computer, follow these steps:

• Write an assembly program, using a text editor such as Microsoft Notebook.

- Save the file as text only, using a ".*asm*" extension, in the same directory as the Basic Computer Assembler.
- Using Windows Explorer or a command window, start the assembler.
- When the assembler comes up, enter the name of your file with *.asm* extension.

Се11 <i>НН</i>	Cell Value	kput (Code
001	2003		ldc \$3 //load immediatly AC by 3
002	4784	tl:	add 900 // add memory contents of address 90
003	2800		dsz // decrement and skip if zero
004	63E8		buntl: //brunch unconditionaly to tl:
005	5F85		sta 901 // store AC in memory location 901
006	180F		1da \$15
007	3C10	t2:	sla1 // shift right AC by 3
800	7BE9		bet2: //brunch if carry to t3:
009	3C40		halt //halt
Da	ta Segn	erit.	
Line	Hex 1	Decimal	
900	0002	2	
Br	ench Ve	ctor Tab	le
Line	Hex I	Decimal	
1000	0002	2	
1001	0002	2	
1001			

Fig. 7: Listing file of an assembly program.

Three new files are generated in the directory, the assembly language file with extensions *.mem*, and the list file with *.lst* extension (see Fig. 7), and the binary file have a "*mem1.dat*" name.

SIMULATION AND FPGA IMPLEMENTATION

Once files defining mico-operations are ready, the proposed computer can be entirely simulated with the simulator included in the Xilinx Development Environment. This is found particularly important to help students to;

- understand what is going on and why,
- check that obtained values from simulation confirm to what is expected,
- verify and follow the progression of the signals directly on the screen, since it matches the architecture layout given in Fig. 5.

Figure 8 shows the trace window for the signals generated by the assembly program given in Fig.7. By examining the control signals, contents of computer registers and memory at address 1 to 9 and at addresses 900, 901 1000 and 1001, we can determine whether the prototype is functioning correctly or not? Once we have

	/clock	-1					היייייייייייייייייייייייייייייייייייייי			փուսոսոս	ההרונונונים	hononon	hunnun			M
- 🔶	ddddd/rst	-1														
⊕	/out11	32	(1_))))))	#XXXXX#C	0000000000	0000000	0000000000	∞	#XXXXXX	XXXXXXXXX	(#)))))))#	000000000000000000000000000000000000000	100000000000000000000000000000000000000	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	ວງສາວງງງງ	XX
. ⊞	d/atog	1	(1)))(1	0001_000	1))))))1	0000100	<u>)))1))))1</u>		<u>1001000</u>	1))1 🗶	0001000	<u> </u>	XXX1 XXX	axaxat	Д
. ⊞	/PC0	10	0 (1	2 3	4)5	<u>)</u> 2)3	4	<u>)(5)</u>	2)3	<u>X4 X X</u>	6 <u>(</u>	7 <u>(</u> 8	<mark>)</mark> 9)(10) (8)(9)	
⊕	/ARO	8	0	<u>)</u> 3).	124 <mark>)</mark> 0	.24	<u>)</u> 2 <u>)</u> -12	4 <u>X</u> O	(-24)2	.124	<u>X</u> O	-123	8)-2	23 8	
⊕	MARO	0	0	1 2	X X3	0 (4)-2	4 <u>(</u> 2).	. 🔏 🚺	X4 X-24	X2 X	<u>3 XO X</u> 5	(-123) E	7	8 9	<u> XO X8</u>	
⊕	/ACO	0	0		2			X 4		Xe			X3 X1	0		
⊕	INPRO	0	0													
⊕	MBRO	8	0	X1 X	<u>)</u> 2)	<u>X4 X X</u>	2 X X	2 X X4	<u>)</u> <u>)</u> 2	X X2	<u>X X4 X</u>	<u>) () ()</u>	15368	X	<u> X8 (10)(1</u>	
⊡>	OPRO	-2	0	<u>(</u> -5)	1 <u>X</u> -6	; <mark>(</mark> -8	<u>)(</u> 1) -6	<mark>)</mark> -8	1	<u>)</u> -6	7	-1	(-2	2 X	1
⊡	ddddd/co	0	0	3		2		(1			χo					
⊡	dd/w1	001011	()00101	1000000	0011											
⊡	dd/w2	010001	()(01000)	1111000	0100											
⊡	dd/w3	001010	()00101	0000000	0000											
⊞	dd/w4	011000	()(01100)	0111110	1000											
⊞	dd/w5	010111	()01011	1111000	0101											
⊞	dd/w6	001111	()00111	1000000	1000											
⊡>	dd/w7	001111	()00111	1000000	1000											
⊡	dd/w8	001111	()00111	1000000	1000											
⊡	dd/w9	011110	()(01111)	0111110	1001											
⊡	/w900	000000	()(00000)	0000000	0010											
⊡	/w901	000000	(000000)	0000000	000							(00	<u> 00000000</u>	0000110		
⊡	w1000	000000	()(00000	0000000	0010											
⊡	w1001	000000	()(00000	0000000	1000											
			1	1.1.1	L 50		1	1		150		2	00		250	1
			-													

J. Computer Sci., 3 (8): 624-632, 2007

Fig. 8: Waveforms Generated by the Program in Fig. 7.



Fig. 9: Teaching Tool Screen.

determined that the design is functioning correctly we are ready to proceed to the synthesis and device programming to generate a configuration that will program an FPGA device to implement the proposed computer system.

Field programmable gate arrays are a class of programmable logic devices based on an array of logic cells surrounded by a periphery of input/output cells. These programmable integrated circuits can be programmed in the field to implement specific design function. A basic computer architecture is created from the ground up as a scalable architecture, covering the basic operations in 16-bit processor domain.

The general layout of the user I/O user interface of the teaching tool is given in Fig. 9. An I/O interface is connected to the FPGA board to input any command or data from the student and to monitor current values of all registers, flags and related memory locations.

There are eight slide switches (SW_0-SW_7) in the system. Switches (SW_{4-7}) are used as input data, switches $(SW_1 \& SW_2)$ are used as external

able 7. Device Characteristics										
Device: Xilinx Spartan-3 XC3S200FT256										
Slices: 3584, 256-ball thin Ball Grid Array										
System Logic cells Multipliers blocks Digital Max I/O										
(18*18) Clock Signal										
Managers										
200 k 4320 12 4 173										
Select RAM In-system Fast Asynchronous										
18K-bits Max RAM programmable SRAM										
Blocks K-bits configuration										
PROM										
12 216 2 M-bits 1 M-byte										
	216 Device: Xili Slices: 3584 Logic cells 4320 RAM Max RAM K-bits 216	Device Characteristics Device: Xilinx Spartan-3 XC3S Slices: 3584, 256-ball thin Ball Logic cells Multipliers blocks (18*18) 4320 12 RAM In-system Max RAM programmable K-bits configuration PROM 216 2 M-bits	Device: Xilinx Spartan-3 XC3S200FT256 Slices: 3584, 256-ball thin Ball Grid Array Logic cells Multipliers blocks (18*18) Clock Managers 4320 12 RAM In-system Max RAM programmable K-bits configuration PROM 216 2 M-bits							

Table 7: Device Characteristics

Table 8: Macro Statistics

ROMs	16x7-bit
Registers	17
Counters	3
Multiplexers	7
Tri-states	27
Decoders	2
Adders/Subtractors	4



Fig. 10: Design Flow Map

Table 9: Utilization Su	ımmar
-------------------------	-------

Table 9. Othization Summary					
	Item	Used	Available	Percentage	
	Slices	433	3584	12%	
	Slice Flip Flops	114	7168	1%	
	4 input LUTs	802	7168	11%	
	Bonded IOBs	23	173	13%	
	GCLKs	2	8	25%	

interrupts, while switch (SW_0) is used to indicate if the clock is a system clock or a user clock. Figure 10 shows the design procedure of the basic computer. Table 7 shows the different characteristics of the FPGA board used in the implementation^[11,12]. Tables 8 and 9 show the macro statistics and FPGA resources are shown in Tables 8 and 9 respectively.

CONCLUSION

This paper addressed the importance of using computer simulation and FPGA realization in learning computer organization and architecture. The given teaching tool can be considered as a useful practical addition to computer engineering and computer science curricula. This teaching tool helps computer engineering and computer science students to be familiarized practically with computer organization and architecture through development of their own instruction set and computer programming and interfacing experiments. In this paper;

- The simulation of a single cycle basic computer and the implementation of an assembler has been presented.
- The micro-operation of the computer module and its assembler are implemented on Xilinx Spartan-3 FPGA board, since it offers good code density, easy customization, easily developed software, high performance and small area.
- It is worthwhile to mention that this teaching tool has been developed and implemented using popular Xilinx boards found in many universities. It has been tested by 3rd year undergraduate students enrolled at the computer architecture course given at Philadelphia university-Jordan. The students performed better when they used this teaching tool.
- The codes of the various modules are implemented and tested with a program which utilizes every instruction as well as exercises the critical paths of the chip.
- This FPGA application runs at a maximum frequency of 73.465 MHz.

REFERENCES

- 1. Holland, M., J. Harris and S. Hauck, 2003. Harnessing FPGAs for computer architecture education, Proceedings of the IEEE Intr. Conf. on Microelectronic Systems Education (MSE03), USA.
- Hatfield, B. and M. Rieker, 2005. Incorporating simulation and implementation into teaching computer organization and architecture", 35th ASEE/IEEE Frontiers in Education Conf, Indianapolis, USA, pp: FIG-18.
- Al-Aubidy, K. M., R. F. Al-Bader and A. A. Samadi, 2005. Simulation and FPGA implementation of a simple computer. The 7th Middle Eastern Simulation Multiconference "MESM2005", Porto, pp:151-158.
- Quintans, C. and M. D. Valdes, L. Fernandez-Ferreira, M. J. Moure & E. Mandado, 2005. Digital electronics learning system based on FPGA applications, 35th ASEE/IEEE Frontiers in Education Conf, Indianapolis, USA, pp: S2G-7.
- Li, Y. and W. Chu, 1996. Using FPGA for computer architecture/organization education, EEE Computer Society Press, USA, pp.31-35.

- Sugawara, Y. and K. Hiraki, 2006. A computer architecture education curriculum through the design and implementation of original processors using FPGAs, 36th ASEE/IEEE Frontiers in Education Conference.
- Hennessy, J. L. and D. A. Patterson, 2003. Computer architecture: a quantitative approach, Morgan Kaufmann, USA.
- 8. Ciletti M. D., 2002. Advanced digital design with the Verilog HDL, Prentice Hall, USA.
- 9. Yalamanchili S., 2001. Introductory VHDL: from simulation to synthesis, Prentice Hall, USA.
- Krid M. and D. S. M. Masmoudi, 2005. FPGA implementation of a feedforward neural network, 3rd Intr. Conf. on Systems, Signals & Devices (SSD05), Tunisia, pp: .
- 11. Digilentic Co, 2004. Spartan-3 starter kit board user guide, Digilentic Co., www.digilentinc.com.
- ST Microelectronics, 2004. Design guide for Xilinx FPGA power management systems, ST Microelectronics, Version 1.2, pp.1-11.